

Wall to Wall

Step by step installation guide



Creative Drain Solutions™




Image of installed final product

Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Installation Guide

These installation details are intended to be used as a guide only; we advise specific projects follow engineering advice and Australian Standards.



Creative Drain Solutions™

Required for installation

Tools

- Marker
- Drill / Screw Driver
- Scotch brite
- Clean cloths
- Scraper
- Brush
- Paint brush or roller
- Caulking gun
- V-notch or Square notch trowel
- MDF Spacer or alternate
- Roller tray
- Bucket

Materials

- Stainless steel screws
- Solvent or recommended cleaner
- Selected primer
- Waterproofing compound
- Adhesive / Sealer
- Mortar
- Selected tiles
- Color matched grout
- Color matched tile silicone

Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.


Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Set up floor area with rebate to match drain.

Install ceramic tile underlay to manufacturers specifications; graded toward the drain per Australian Standards.




Creative Drain Solutions™

STEP

1

TYPICAL LAYOUT
Wall to Wall



These installation details are intended to be used as a guide only;
we advise specific projects follow engineering advice and Australian Standards.

Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain Solutions

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Temporarily place the drain channel in position and mark extremeties (including flanges and fixing tags).




Creative Drain Solutions™

STEP

2

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Create a 2mm rebate along the marked extremities to allow for the drain to floor flashing to sit in.



Creative Drain Solutions™

STEP


3

2mm Rebate



2mm
rebate

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Clean entire floor area, apply a suitable surface primer and then apply a propriety waterproofing compound. ie Acrylic or Polyurethane compound to Australian Standards.





Creative Drain Solutions™

STEP

4

TYPICAL LAYOUT
Wall to Wall






Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Apply Polyurethane adhesive/sealant onto rebated area where wall and floor flashings meet.




Creative Drain Solutions™

STEP

5

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Locate the drain channel and predrill screw holes.

Fill each hole with selected polyurethane sealant prior to screwing into place with Stainless Steel screws.

Cover the head of each screw again with sealant and allow to cure prior to preparing for primer.






Creative Drain Solutions™

STEP

6

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain Solutions

Ph: (03) 9758 0588



creativedrainsolutions.com.au

Identify where the tile will be placed and where primer will be required.

Use the provided scouring pad to 'roughen' up the surface where the primer is to be applied using the scourer in a criss-cross motion over the flanges.

Wipe clear of dust and debris.

Only use scotch brite scoring pads for use on stainless steel. Do not use steel wool or other steel scourers.




Creative Drain Solutions™

STEP

7

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain Solutions

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Paint on supplied primer to prepared flange faces to ensure that the waterproofing will adhere to the drain flanges.

Ensure the weep holes are kept free of primer and blockage.






Creative Drain Solutions™

STEP

8

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Apply a second layer of waterproofing over the drain floor and wall flashings, (ensuring the slot weep holes are not covered).




Creative Drain Solutions™

STEP

9

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**


Ph: (03) 9758 0588

creativedrainsolutions.com.au

Trowel mortar with a V-notch or Square notch trowel in direction of fall, being cautious to follow manufacturers specifications.

Ensure weep holes are kept clear of mortar.

Use a removable spacer (MDF, plastic or similar) along the tile retention lip edge to space tiles away from edge.




Creative Drain Solutions™

STEP

10

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Tiles laid with fall to drain.
Keep tiles to 1mm above drain lip.




Creative Drain Solutions™

STEP

11

TYPICAL LAYOUT
Wall to Wall



Fall



fall

Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Tiles laid with fall to drain.
Keep tiles to 1mm above drain lip.
Grout as required.




Creative Drain Solutions™

STEP

12

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au



Remove packing and seal (top 3mm deep)
the gap between the tile retention lip and
tiles.



Creative Drain Solutions™

STEP
13

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au

Give the tile and drain a clean with warm soapy water to ensure no dirt, or debris remains, and rinse with warm water.

Fit Grate or Tile Insert Tray in place and rinse clean.

Now you can enjoy your new Creative Drain and tiled wet area.




Creative Drain Solutions™

STEP

14

TYPICAL LAYOUT
Wall to Wall



Disclaimer: These drawings are the intellectual property of Creative Drain Solutions. This information is indicative only. Creative Drain Solutions accepts no liability arising from the use of this information.

Creative Drain **Solutions**

Ph: (03) 9758 0588

creativedrainsolutions.com.au